

Night Stalkers

TREX 150 DFC - MINI LED NIGHT KIT

Installation:

1. Start by installing the tail LED (longest lead) by securing the LED approx. 1" away from the tail fin with one of the included cable ties. Bend and point the LED towards the tail at roughly 45 degrees. You may want to play with this to get it how you like it.

2. Run the wires towards the front of the helicopter by securing along the boom, then remove a side servo to run wires behind it, then reinstall servo.

3. Mount the front LED (short lead) on top of the FBL Unit and secure with one of the included cable ties.

4. Excess wire can be tucked away around the front of the Heli, make sure to keep clear of the Main Motor.

5. Solder the ends of the wires to the top side of the Battery Input Board, make sure to match + and -.

Make sure when installing the LED Kit to have plenty of clearance between the tail blades and LED!!!

IF YOU HAVE ANY QUESTIONS FOR INSTALLATION, PLEASE CONTACT US VIA OUR SUPPORT SYSTEM LOCATED ONLINE AT:

[HTTP://SUPPORT.PERFECTREGULATORS.COM](http://support.perfectregulators.com)

