

5v Gyro / Tail Servo Voltage Regulator

How To Connect The Regulator

Male Plug - To Rx Rudder Channel
(or Gyro Output)

Female Plug - To Gyro
(or Tail Servo)

