

DUO



How To Connect The Duo

Connect the included Male to Male Extensions from the Duo to the Rx's channels you wish to regulate to 5.3v. Connect the corresponding Servos to the output on the unit. Make note to follow the pin configuration when making the connections.